

CONDUIT AIR TEST INSTALLATION INSTRUCTIONS:

1. CHECK CONDUIT ENDS FOR BURRS CAUSED BY REMOVAL OF SHIPPING BARS. REMOVE BURRS ON SHARP EDGES BY GRINDING OR FILING SO THAT A PROPER SEAL MAY BE ACHIEVED.
2. SLIDE TEST CAP OVER OPEN END OF CONDUIT, BUTTING UP TO RUBBER GASKET PLACED BETWEEN CONDUIT END AND TEST CAP.
3. TIGHTEN TEST CAN NUT AND BOLT ASSEMBLY ON RING PLACED OVER CONDUIT END UNTIL THE NUTS AND BOLT ASSEMBLY CANNOT BE TIGHTENED ANY FURTHER.
4. SNUG UP TEST CAN TO END OF CONDUIT, SO THAT RUBBER GASKET SEALS TIGHTLY BETWEEN TEST CAN, AND OPEN END OF CONDUIT.
5. **ATTACH SAFETY CHAIN TO THE TEST CAN IN LUGS PROVIDED, AND WELD CHAIN TO CONDUIT.**

CAUTION: "DO NOT" WALK IN FRONT OF THE TEST CAN DURING PRESSURIZATION !!
6. AFTER TESTING IS COMPLETE REMOVE TEST CAN AND GASKET.

TEST CANS FOR MAXIMUM 15psi AIR TEST.

